

INSTRUCTIONS



PUTTING ON THE ARMS BEARER™.

STEP 1:

Use the ARMS BEARERS™ Velcro tabs to get a snug fit.



STEP 2:

Buckle the belt.



ADJUSTING THE BELTS:

First disconnect the slid lock and buckle on the belt and slide the belt out of the adjustment loop.



Then slide the belt through the preferred adjustment loop. Then reconnect the slide lock and buckle. Repeat the process for the opposite belt.



ATTACHING A GUN.

STEP 1:

To attach your gun, cradle it and by using both hands buckle the lower belt.



STEP 2:

Buckle the top belt.




Your gun is now secured to you



TO RELEASE A GUN.

STEP 1:

Hold your gun by the stock's grip, and release the lower buckle with your free hand.



STEP 2:

Release the top buckle.



STEP 3:

Your gun is now free to shoot.

With practice you can be as fast or quiet as you chose.



ATTACHING A BOW.


STEP 1:

Cradle your bow with the string down. Buckle the lower belt under your stabilizer.




STEP 2:

Buckle the top belt around the riser.




Your bow is now secured to you



TO RELEASE THE BOW.


STEP 1:

Grab the bow by the grip with your bow hand and with your free hand release the lower



STEP 2:

Release the top buckle with your free hand.



STEP 3:

Your bow is now free to shoot.

This right handed archer is holding the bow with left hand.